



**MIRABOOK**

---

USER MANUAL

**MIRAXESS**

# INTRODUCTION

This manual contains all the information you need to use the Mirabook in good conditions.

It also contains all restrictions to be carefully avoided so as not to damage the device and ensure the safety of the user.

Follow this user manual as strictly as possible for you to ensure the validity of the warranty in case of issue.

**NOTE:** the Mirabook uses DisplayPort technology for video transfer, which makes it non-compatible with some Smartphones and other devices, this will NOT be considered as an issue for repair, replacement or refund.  
For more information about compatible systems, please go to our website:

**[www.miraxess.com](http://www.miraxess.com)**


**WARNING:** In case of damage or malfunction of the Mirabook, do not attempt to repair by yourself, contact the support team of Miraxess ([support@miraxess.com](mailto:support@miraxess.com)) or the support of your reseller.

# CONTENTS


What's in the box?.....	4
External ports.....	5
Keyboard and notifications Icons.....	6
Positioning the Colour touch.....	7
Installation of the USB-C Cable.....	8
Turning ON the Mirabook and plugging the Smartphone (or device).....	10
Unplugging the Smartphone (or device) and turning OFF the Mirabook.....	11
Safety precautions.....	12
Warranty and Support.....	14
Certifications.....	15

# WHAT'S IN THE BOX

1 x Mirabook




1 x Color Touch



1 x USB-C to USB-C cable



1 x USB-C charger with cable




1 x Mirabook User Manual






# EXTERNAL CONNECTORS




**WARNING:** do not insert anything but the official accessory «The Slide» into the dedicated slot (number 5 in the picture above) as it may damage it.

# KEYBOARD AND NOTIFICATIONS ICONS




10

11




1. Trackpad on/off
2. Backlit on/off
3. Volume down
4. Volume up
5. Screen brightness down
6. Screen brightness up
7. Battery Level
8. Smartphone/device charging on/off
9. HDMI out on/off
10. MiraKey, menu/all apps key
11. Right Click Key
12. Mirabook Charging on/off LED
13. Smartphone/Device charging on/off LED
14. Caps Lock on/off LED


## COLOR TOUCH POSITIONING



1. Tilt the Color Touch and place it, head first, as shown in the image above




2. Lay the rest of the Color Touch as shown in the image above




3. Push the Color Touch until you hear a click and feel it locked

4. To take off the Color Touch, just reverse the process above-mentioned


## USB-C CABLE INSTALLATION




1. Turn the Mirabook to install the cable in its slot.




2. Align the cable on the rail adapted for it.



3. Push the cable until you feel or hear a «click».




3. To lock the cable on the colour touch, fold it against the touch.




4. Hold it with the colour touch pins.

# HOW TO TURN ON/OFF THE MIRABOOK




1. Press the «ON/OFF» button for 1 second to turn «ON» the Mirabook.



2. A message inviting to «connect your device» will appear. Take out the cable from the cable holder.



3. Connect your device to the USB type C cable and the video display should start.



4. To turn «OFF» the Mirabook, press the «ON/OFF» button a few seconds then unplug your device.

# SAFETY & PRECAUTIONS

The following precautions will increase the life of the Mirabook.  
Failure to follow these precautions may result in injury or damage.

**It is strongly recommended to use common sense.**



**DO NOT** place on uneven or unstable work surfaces.  
Seek servicing if the case has been damaged.



**DO NOT** expose to dirty or dusty environments.  
**DO NOT** operate during a gas leak.



**DO NOT** expose or place under any liquids, heavy steam  
or strong humidity.



**DO NOT** place or drop any objects on top.  
**DO NOT** shove any foreign objects into the Mirabook.





**DO NOT** expose to strong magnetic or electrical fields.



**DO NOT** expose to strong heat or fire.



**BATTERY SAFETY WARNING:**

**DO NOT** throw the battery on fire.  
**DO NOT** short circuit the contacts.  
**DO NOT** disassemble the battery.  
**DO NOT** drop any objects on the battery.



**DISPOSAL OF THE MIRABOOK AND BATTERY**

**DO NOT** throw the Mirabook in municipal waste.  
The Mirabook has been designed for proper reuse of parts and recycling.  
Check local regulations for disposal of electronic products.



**DO NOT** try to open or dismount the Mirabook. You may suffer injury or make the mirabook malfunction.

Miraxess S.A.S is not responsible for any injuries or damages caused by the non-respected «Safety & Precautions» guidelines of this manual.

# WARRANTY AND SUPPORT

## Warranty

Miraxess provides all customers **24 months** warranty from the date of purchase.

If the device fails due to manufacturer defects, please contact us by e-mail at [support@miraxess.com](mailto:support@miraxess.com) to launch a warranty claim. We will instruct you how to return the product for repair/replacement.

We can only provide after sale service for products purchased directly from Miraxess or Miraxess authorized distributors. If you have purchased from a different seller, please contact them for any request.

**The warranty may NOT be valid in case of non-respected «Safety & Precautions» guidelines of this manual.**

**Note:** The warranty of the Battery is 12 months from the date of purchase of the Mirabook

## Support

For all inquiries, please contact us with your purchase number or reference for dealing with the issue quicker.


E-mail: [\*\*support@miraxess.com\*\*](mailto:support@miraxess.com)

# CERTIFICATIONS

## Mirabook Main Certifications



The Mirabook is completely removable for better recycling of components. **Please respect and follow local guidelines for electronic waste and recycling.**



Find more information on our website

**[www.miraxess.com](http://www.miraxess.com)**

## RECOMMENDATIONS



1. It is strongly recommended, for a better operation and maintenance of the device, to turn «**OFF**» the Mirabook **BEFORE** unplugging your device.

3. The provided charger is only intended to work with the Mirabook, **DO NOT** use it to charge other devices.

2. It is strongly recommended to use the Mirabook in a stable and even surface when one or several external connections are in use. This is due to the potential heat released by the device when one or more ports are in use.

Please be careful if the Mirabook starts heating, **DO NOT** place the heating zones directly on the skin or flammable materials.

«We foresee a world where we have one pocket computer that is capable of powering full-featured devices.

The Mirabook Extension fits into this natural motion that makes the smartphone the universal engine of our digital activities.

This mobile convergence is the heart of Miraxess, and we will continue to innovate in this direction.»

MIRAXESS